

Table of Contents

Chapter 1 Installation Procedures

Clear Password: CPS	2
Flash EPROM Type Selection: EP1, EP2	2
CPU External Clock (BUS) Frequency: CLK1, CLK2, CLK3	3
CPU Internal Freq. to Bus Clock Ratio: FREQ1, FREQ2, FREQ3	3

Chapter 2 BIOS Setup

Award BIOS Setup.....	5
CMOS Setup Utility	5
Standard CMOS Setup.....	6
Hard Disk Configurations.....	6
Software Turbo Speed	7
BIOS Features Setup	7
Chipset Features Setup.....	10
Power Management Setup	12
PNP/PCI Configuration Setup.....	16
Load BIOS Defaults	18
Load Setup Defaults	18
Integrated Peripherals	19
Supervisor/User Password	23
IDE HDD Auto Detection.....	23
Save and Exit Setup.....	24
Exit without Saving	24

This Page Intentionally Left Blank