

Table of Contents

Chapter 1 Overview

Package Checklist	1
The PA-2013 Motherboard.....	2
Main Features.....	3
Intelligent Properties.....	5

Chapter 2 Installation Procedures

1). Set System Jumpers	7
Jumpers	7
Motherboard Layout.....	8
Clear Password: CPS	10
Flash ROM Type Selection: EP1, EP2	10
CPU to SRAM Data Transacting Mode Selection: SRAM	11
2). Install System RAM Modules.....	11
RAM Module Configuration.....	11
Install and Remove DIMMs.....	12
DIMM Frequency: CLK4, SDRAM	13
System Frequency: NBCLK1, NBCLK2	13
Cache Memory.....	14
3). Install the CPU	15
CPU External (BUS) Frequency: CLK1, CLK2, CLK3	16
CPU to Bus Frequency Ratio: FREQ1, FREQ2, FREQ3.....	16
Set CPU Frequency:	17
Set CPU Voltage	18
4). Install Expansion Cards	19
5). Connect Devices	20
Connect to Internal Devices.....	20
Floppy Diskette Drive Connector: FLOPPY	20
IDE HDD Device Connectors: PRIMARY, SECONDARY	20
ATX Power Connector: POWER.....	20
CPU Fan Connector: FAN1	21
Wake-On-LAN (WOL) Connector: RWU	21
Connect to System Case	22
Front Panel Block Connector: F_PNL	22
System Case Fan Connector: FAN2.....	24
Chassis Intrusion Alarm Connector: CHASSIS1	24
Connect to External Devices.....	25

PS/2 Keyboard and Mouse Connector: KB/MS.....	25
Universal Serial Bus Connectors: USB0, USB1, F_USB	25
Printer Connector: LPT	26
Serial Port Connectors: COM1, COM2	26
Infrared Connector: IR	26

Chapter 3 BIOS Setup

CMOS Setup Utility.....	27
Standard CMOS Setup	28
Hard Disk Configurations.....	28
Software Turbo Speed	29
BIOS Features Setup.....	29
Chipset Features Setup.....	32
Power Management Setup.....	35
PNP/PCI Configuration	39
Load BIOS Defaults	41
Load Setup Defaults.....	41
Integrated Peripherals	42
Supervisor/User Password.....	46
IDE HDD Auto Detection.....	46
Save and Exit Setup	47
Exit without Saving.....	47

Chapter 4 Software Utilities

Starting Installation.....	49
LANDesk Client Manager (manufacturing option).....	49
LDCM 3.21 Specification Overview	49
Two Options of LDCM Setup	50
Desktop Management Interface (DMI).....	51
Starting DMI.....	51
Editing DMI.....	51
Adding DMI.....	52
Loading DMI	52
Saving DMI	53
Bus Master IDE Driver	54
Installation.....	54
Patch for Chipset.....	55

Table of Contents

Installation	55
AGP VxD Support Utility	56
System Requirements.....	56
Installation	56
BIOS Flash Software.....	57
Downloading BIOS File	57
Upgrading BIOS File.....	57
Loading New BIOS Defaults	58
Anti-Virus Tool.....	58
Hardware Requirements.....	58
Technical Notes	58

This Page Intentionally Left Blank