



**PS/2 Keyboard Connector: PS2\_KB**

This 5-pin female connector is used for your PS/2 keyboard.




**PS/2 Mouse Connector: PS2\_MS**

This 5-pin female connector is used for your PS/2 mouse.



**Remote Power Connector: RPW\_CON**

This 3-pin male connector allows you to enable or disable the system power if the RPW\_SW is on or off. (This allows you to adapt the remote power switch feature. Please contact your dealer for further information.)



**Universal Serial Bus Connector: USB1 and USB2**

This connects to the port that allows you to attach a USB hub. The USB1 and USB2 connectors are built-in for future upgrade of devices or peripherals that support Universal Serial Bus features.

