

Table of Contents

Chapter 1 Installation Procedures

Clear CMOS: SW1-5	2
Clear Password: SW1-6	2
Flash ROM Type Selection: EP1, EP2	3
Keyboard and Mouse Power-On Feature: KB_PWN	3
CPU Internal Frequency: SW-1, SW-2, SW-3, SW-4	4

Chapter 2 BIOS Setup

Main Setup	5
Advanced Setup	6
Advanced CMOS Setup	7
Advanced Chipset Setup	12
Power Management Setup	16
PCI/Plug and Play Setup	21
Peripheral Setup	25
Hardware Monitor Setup	27
Security Setup	28
Exit Setup	29