

Table of Contents

Chapter 1 Overview

Package Checklist.....	1
The Mainboard.....	2
Main Features	3
ACPI Ready.....	5

Chapter 2 Installation Procedures

Quick Reference (Jumpers).....	8
Quick Reference (Connectors)	10
1). Set System Jumpers/Switches	12
Clear CMOS: SW1-5	12
Clear Password: SW1-6	12
Keyboard and Mouse Power-On Feature: KB_PWN.....	13
2). Install RAM Modules	14
RAM Module Configuration	14
Install and Remove DIMMs	15
3). Install the CPU	16
I). Install with Foldable Retention Mechanism Assembly	16
II). Install with Non-Foldable Retention Mechanism Assembly	18
CPU Internal Frequency: SW-1, SW-2, SW-3, SW-4.....	21
4). Install Expansion Cards	22
5). Connect Devices.....	23
Connect to Internal Devices	23
Floppy Diskette Drive Connector: FLOPPY.....	23
ATX Power Connector: POWER	23
IDE HDD Device Connectors:	
PRIMARY, SECONDARY	24
CPU Fan Connector: FAN1	24
Wake-On-LAN Connector: WOL.....	25
PCI Audio Card Connector: SB_LINK.....	25
Connect to System Case.....	26
Front Panel Block Connector.....	26
System Case Fan Connector: FAN2	27

Printer Connector: LPT	28
PS/2 Keyboard and Mouse Connector: KB, MS	28
Infrared Connector: IR	29
Universal Serial Bus Connectors: USB0, USB1, J1	27

Chapter 3 Software Utilities

Starting Installation	31
Virus Detection Agent	31
IDE Bus Master	33
Installation	33
Patch for Chipset	34
Installation	34
AGP VxD Support Utility	35
System Requirements	35
Installation	35
Adobe Acrobat Reader	35
Browse CD	35
Install Audio/LAN/Video Driver	36
First AID	36
LANDesk Client Manager CD (optional)	36
Specification Overview	37
Two Options of LDCM Setup	38

Chapter 4 BIOS Setup

AMI BIOS Setup	39
Main Setup	39
Advanced Setup	40
Advanced CMOS Setup	40
Advanced Chipset Setup	45
Power Management Setup	48
PCI/Plug and Play Setup	52
Peripheral Setup	55
Hardware Monitor Setup	57
Security Setup	58

Table of Contents

Exit Setup	59
AMI BIOS Flash Software	60
Downloading BIOS File	60
Upgrading BIOS File.....	60
Loading New BIOS Defaults	61
Award BIOS Setup	61
CMOS Setup Utility	61
Standard CMOS Setup.....	62
Hard Disk Configurations.....	62
Software Turbo Speed.....	63
BIOS Features Setup	63
Chipset Features Setup.....	66
Power Management Setup.....	69
PNP/PCI Configuration	72
Load BIOS Defaults	74
Load Setup Defaults.....	74
Integrated Peripherals	75
Supervisor/User Password.....	79
IDE HDD Auto Detection.....	79
Save and Exit Setup	80
Exit without Saving.....	80
Award BIOS Flash Software	80
Downloading BIOS File	80
Method 1: Upgrading BIOS File under DOS.....	81
Loading New BIOS Defaults	81
Method 2: Flash BIOS During POST.....	81
BIOS Features Setup (for VB-601 only).....	82
Chipset Features Setup.....	85
Power Management Setup.....	87
PNP/PCI Configuration	92
Integrated Peripherals	93

This Page Left Blank for Note